


Recommended Wiring for Pulsar 11-1180-0-0, 11-1100-0 and Suntail 11-1160 Lights
Wire run for one light shown below



Note: breaker sizes will depend on number of lights installed
 14V: Budget 0.5 A per Suntail or Pulsar Position Light Input
 14V: Budget 5A per Suntail or Pulsar Strobe Light Input
 28V: Budget 0.25 A per Suntail or Pulsar Position Light Input
 28V: Budget 2.5A per Suntail or Pulsar Strobe Light Input

To other strobe green wires for synch