



* If Wig Wag controller is not installed wire lights as shown and connect Yellow Wires to Red wire.
 If only one mode is desired then the other wire (purple or brown) should be capped and stowed

Mode	Red	Blue	Yellow	Black
Taxi (5 LEDs)	Power	Ground	Power	Ground
Landing (1 LED)	Power	Power	Power	Ground